

Royal Safe PL

YOUR NEW ELECTRONIC SAFE INITIAL CODE IS SET AT

* 1 2 3 4 #

*** We recommend that you immediately change this code to your own personal code ***

HOW TO SET YOUR OWN PERSONAL CODE (MAXIMUM 8 DIGITS)

1. Press the "M" button (memory button) on the door back cover.
2. On the keypad enter your new code number (you can program in 2-to 8 digits) followed by # (Example 123456#).
3. Your code is now set with the new number and you open your safe by pressing *new number # (example *123456#)

HOW TO USE YOUR ELECTRONIC SAFE

1. Insert the key in the cylindrical lock.
2. Turn the inserted key to the right.
3. Press your personal code .(*number #) within 4 seconds to keep door from locking automatically.
4. Pull the handle to open the door.
5. If a wrong code is attempted 4 times, the locking system will not work for 5 minutes.
6. If battery charge is low, " Lo Ba " will appear in the LCD window and the batteries (Alkaline) must be replaced.

HOW TO LOCK THE SAFE

Shut the safe door and insert the key in the cylindrical lock and turn it to the left. The safe is now double locked by both key and electrical locking functions.