Short version of Code Combi B (1 t/m 6) manual

Available with user code (2e code)

To program code

Open the safe with the standard code 1 2 3 4 5 6 or a new code that has been programmed by you .

Program the code with an open door and the lock in open position
1. ON
2. P
3. Current Code
4. New Code
5. New Code green light flashes 1x (Code activated)

Program time delay and openings time delay

Open the safe with the standard code 1 2 3 4 5 6 or a new code that has been programmed by you .

Program the code with an open door and the lock in open position
1. ON
2. P
3. Current Code
4. P
5. 1
6. Program time delay (01 min t/m 99 min)
7. Program opening time delay (1 min t/m 9 min)

Example 152 → 15 min time delay
2 min openings time delay

Code Combi B cancellation of signals (red and green light are flashing)

1. ON
2. P
3. Current Code
4. P
5. Press 9

Programmed code is not known

Open the safe with the emergency key, leave the key in the lock in open position
1. ON
2. P
3. P
4. 0
5. ON
6. P
7. New Code
8. New Code green led flashes 2x